


## Notice de démontage/remontage pour nettoyage Manche préhenseur-impacteur de cupule

Références associées	Désignation	Nombre de composants
B223112	Manche préhenseur-impacteur de cupule	4



### Etapes de démontage/remontage pour nettoyage


Pour le nettoyage du manche, le démontage est **obligatoire** :

1. Dévisser la bague à butée
2. La faire coulisser le long du corps ;
3. Sortir le ressort de la bague coulissante et faire coulisser la bague coulissante ;
4. Nettoyer l'ensemble du manche, dont la cavité du ressort dans la bague coulissante ;
5. Remonter le tout sans forcer en prenant garde à bien positionner le ressort dans la bague coulissante.

## Instruction for assembly and disassembly for cleaning

# Cup impactor-holder handle

Associated reference	Designation	Number of components
B223112	Cup impactor-holder handle	4



### Steps for assembly/disassembly for cleaning

For the cleaning of the handle, the disassembly is **obligatory**:

1. Unscrew the stopping ring;
2. Slide it along the body;
3. Put the spring out of the sliding ring and slide the sliding ring;
4. Clean the whole, including the housing of the spring in the sliding ring;
5. Assemble the set without force, paying attention to place the spring on the sliding ring.